
**MODELS WITH REVERSE**


Harness side connectors



(Terminal side)

MODELS WITHOUT REVERSE

Harness side connectors



(Terminal side)

RADIO AND CASSETTE DECK

| | | | | | |
|---|-------------------------|----|----------------------------------|----|---------------------------------------|
| 1 | Front right speaker (+) | 9 | Ignition switch ACC (+) | 17 | Ground (-) |
| 2 | Front right speaker (-) | 10 | Headset mic. E (DR) | 18 | Back up (+) |
| 3 | Front left speaker (-) | 11 | Headset mic. (PA) | 19 | Starter reverse switch (comp. muting) |
| 4 | Front left speaker (+) | 12 | Headset mic. (DR) | 20 | Data |
| 5 | Headset mic. E (PA) | 13 | Headset out. (R ch) | 21 | Load |
| 6 | Muting switch ON | 14 | Headset out. (L ch) | 22 | Clock |
| 7 | Search switch up | 15 | Headset out. E Radio switch E | 23 | Ground (data) |
| 8 | Search switch down | 16 | Speed pulse | 24 | Blanking |

RADIO

| | | | | | |
|---|-------------------------|----|----------------------------------|----|-------------------------------|
| 1 | Front right speaker (+) | 9 | Ignition switch ACC (+) | 17 | Ground (-) |
| 2 | Front right speaker (-) | 10 | Headset mic. E (DR) | 18 | Back up (+) |
| 3 | Front left speaker (-) | 11 | Headset mic. (PA) | 19 | Starter switch (comp. muting) |
| 4 | Front left speaker (+) | 12 | Headset mic. (DR) | 20 | Aux. in (R ch) |
| 5 | Headset mic. E (PA) | 13 | Headset out. (R ch) | 21 | Aux. in (L ch) |
| 6 | Muting switch ON | 14 | Headset out. (L ch) | 22 | Aux. in E |
| 7 | Tuning | 15 | Headset out. E Radio switch E | | |
| 8 | Channel/memory | | | | |

MAIN WIRE HARNESS TEST CONNECTIONS

| System Number | System | Terminal | Color | Other Terminal Color | Other Terminal/ Location |
|---------------|---|----------|--|----------------------|---|
| 1 | Speaker circuit | 1 | RED/GRN | ← | Speaker (+) terminal/Front right speaker |
| | | 2 | BRN/BLK | ← | Speaker (-) terminal/Front right speaker |
| | | 3 | GRY/BLK | ← | Speaker (-) terminal/Front left speaker |
| | | 4 | BLU/GRN | ← | Speaker (+) terminal/Front left speaker |
| 2 | Headset | 5 | BLK (sealed) | BLK | 6P-RED mini/On the rear fender |
| | | 10 | BLK (sealed) | (I: BLU) | 6P-RED mini/Inside the fairing (left pocket) |
| | | 11 | RED/BLU | ← | 6P-RED mini/On the rear fender |
| | | 12 | WHT | ← | 6P-RED mini/Inside the fairing (left pocket) |
| | | 13 | YEL | ← | 6P-RED mini/Inside the fairing (left pocket) |
| | | | | ← | 6P-RED mini/On the rear fender |
| | | 14 | LT GRN/RED | ← | 6P-RED mini/Inside the fairing (left pocket) |
| | | | | ← | 6P-RED mini/On the rear fender |
| 15 | GRN/BLK | ← | 6P-RED mini/Inside the fairing (left pocket) | | |
| | | ← | 6P-RED mini/On the rear fender | | |
| 3 | Muting/ search switch circuit | 6 | BLU/BLK | ← | 4P-BLK mini/On the left cooling fan |
| | | 7 | RED/BLK | ← | |
| | | 8 | YEL/RED | ← | |
| | | 15 | GRN/BLK | ← | |
| 4 | Power circuit | 9 | LT GRN/BLK | ← | 10P-WHT/Under the instrument (Reverse models) |
| | | | | ← | 8P-BLK/On the left cooling fan |
| | | 18 | RED/YEL | RED | 8P-BLK/On the left cooling fan |
| | | 17 | GRN | ← | Body ground |
| 5 | Reverse models: Display (LCD unit) circuit | 20 | RED | ← | 14P-BLK/Under the instrument |
| | | 21 | WHT | ← | |
| | | 22 | BLK | ← | |
| | | 23 | BLK (sealed) | ← | |
| | | 24 | GRY | ← | |
| | I: AUX circuit | 20 | BLU/GRN | ← | 3P-WHT/Inside the fairing (left pocket) |
| | | 21 | BLU/YEL | ← | |
| | | 22 | BLK (sealed) | ← | |
| 6 | Reverse models only: AVC circuit | 16 | WHT/BLK | ← | 14P-BLK/Under the instrument |
| 7 | Starter/reverse (I: starter) switch circuit | 19 | YEL/RED | ← | 9P-RED mini/On the right cooling fan |